

# **BLAUPARTS®**

## **WE CARE! *Guidelines For Usage Of Transmission Fluid Pump Kit J91001***

*The following pump is an economical substitute for the expensive Vw VAG 1924 tool as well as other factory transmission fluid filling tools.*

### **! CAUTION !**

**Performing work on your automobile without having proper knowledge, mechanical ability or the proper tools and safety equipment, CAN CAUSE SEVERE INJURY OR DEATH!**

**BLAUfergnügen! Inc. recommends that you have an A.S.E. Certified Technician install your parts to ensure safety. ALWAYS WEAR SAFETY GLASSES AND OTHER SAFETY ITEMS WHEN PERFORMING THE FOLLOWING WORK !**

### **Ravenol Conventional Cap:**

1. For proper use, trim the intake tube to four inches and push it firmly into the bottom of the pump.
2. Trim the rounded tip of the spout off (about a half inch).
3. Firmly push the thirty inches of clear hose onto the end of the spout.
- 4 Carefully place the pump into the transmission fluid bottle and securely thread it closed. Note: Do not tighten it too much. This will cause it to leak.
- 5 Carefully slide the clear fill hose through the transmission filler hole (a.k.a. deflector cap). Direct it in the appropriate direction using your fingers.
- 6 Follow the steps set forth in the factory manual for transmission fluid servicing. Use this pump when it refers to the Vw VAG 1924 tool as well as other factory transmission filling tools.

### **Ravenol Security Cap:**

1. Trim the rounded pump tip spout off (about a half inch). (Image 1)
2. Firmly push the thirty inches of clear hose onto the end of the pump spout. (Image 2)
3. Firmly lift and pull out the bottle spout allowing it to click into place. (Image 3)
4. Un-thread the bottle cap from the bottle spout (counter clockwise).
5. Pull the cap and spout tube up the remainder of the way. (Image 4)
6. Pull and pop the cap off.
7. Together firmly grasp the base of the pump and the bottles spout tube, pushing the pump base into the spout tube. (Image 5)
8. Carefully slide the clear fill hose through the transmission filler hole (a.k.a. deflector cap). Direct it in the appropriate direction using your fingers.
9. Follow the steps set forth in the factory manual for transmission fluid servicing. Use this pump when it refers to the Vw VAG 1924 tool as well as other factory transmission filling tools.



Image 1



Image 2



Image 3



Image 4



Image 5